

# EXPLODED VIEW

## COFFEE GRINDER SUPER JOLLY

ESSJDRO01 06/2003



MAZZER LUIGI s.r.l.  
VIA MOGLIANESE, 113  
30037 GARDIGIANO DI SCORZE' (VE)  
ITALIA  
TEL. +39 041 5830200 r.a. - FAX +39 041 5830060  
E-mail: mazzler@mazzler.com - <http://www.mazzler.com>

No.	DESCRIPTION	CODE	Q.	NOTES
1	Coperchio campana	Hopper cover	1	
2	Campana	Hopper	1	
3	Calamita con anello	Magnet with ring	-	Optional
4	Gasket	S000GUA01	1	
5	Hopper locking slide	SMI0SEB01	1	
6	Coffee grinding adjustment disk	SSJ0GHA02	1	
7	Label: Coarse-fine / Adjustment initial position	S000ETA03	1	
8	Grinding adjustment disk handle	SSJ0PEA04	1	
9	Upper grinding blade holder	SSJ0POA03	1	
10a	Grinding blade set (ref. 33DM)	FMA00033M	1	Single phase versions
10b	Grinding blade set (ref. 33DT)	FMA00033T	1	Three phase versions
11	Lower grinding blade holder	SSJ0POA04	1	
12	Bearing 6202 2Z	S000CUA01	2	
13	Grinding adjustment spring	SSJ0MOB01 A	3	
14	Label: Motor rotation	S000ETA00	1	
15a	Electric cable - "Italy" single phase	S000CAD01	1	
15b	Electric cable - three phase 220-230V	S000CAD09	1	
15c	Electric cable - three phase 380-400V	S000CAD03	1	
15d	Electric cable - "Europe"	S000CAD04	1	
15e	Electric cable - "USA"	S000CAD05	1	
15f	Electric cable - "Australia"	S000CAD07	1	
15g	Electric cable - "Great Britain"	S000CAD08	1	
15h	Electric cable - "Israel"	S000CAD10	1	
15i	Electric cable - "Switzerland"	S000CAD06	1	
16	Cable locking	S000PAB04	1	
17	Drip tray	SSJ0PIB02	1	
18	"Mazzer 4M" plate	S000TAA02	1	
19	Body	SSJ0CAA02 A	1	
20a	Three pole rotative switch	S000INA04 A	1	Three phase versions
20b	Two pole rotative switch	S000INA09	1	Single phase versions
21	Switch plate O / I	-	1	
22	Rotative switch knob	-	1	
23	Motor cover	SSJ0FRA04	1	
24	Ground coffee outlet	S000POA08	1	
25	Ground coffee outlet pipe	S000BOAX2	1	
26	Ground coffee outlet spring	S000MOB09	1	
27	Ground coffee outlet handle	S000MAA04	1	
28a	Pilot light 230-400V - green	S000LAA06	1	Vers. monofase 220-240V/50Hz Vers. trifase 230-400V/50Hz
28b	Pilot light 110V - red	S000LAA01	1	
28c	Pilot light 110V - UL - red	S000LAA07	1	
29	Support legs	S00SPIA01 A	4	
30a	Motor label: SJ 220-240V/50Hz	SSJ0ETA01	1	
30b	Motor label: SJ 220-380V/50Hz	SSJ0ETA03	1	
31	Rotor	SSJ0ROA01	1	
32a	Coiled stator-single phase 220-240V/50Hz	SSJSPAE01	1	Single phase 220-240V vers.
32b	Coiled stator-three phase 230-400V/50Hz	SSJSPAE03	1	Three phase 230-400V/50Hz vers.
32d	Coiled stator-single phase 110V/60Hz - UL	SSJSPAA04	1	Single phase 110V/60Hz vers.
32e	Coiled stator-single phase 220V/60Hz	SSJSPAS01	1	Single phase 220V/60Hz vers.
32f	Coiled stator-three phase 220V/60Hz	SSJSPAS03	1	Three phase 220V/60Hz vers.
33	Motor cap	SSJ0CAB02	1	
34a	Capacitor 8 uF	S000COE01	1	240V/50Hz/1ph. Versions 220V/60Hz/1ph. Versions
34b	Capacitor 10 uF	S000COE02	1	Single phase 220-240V/50Hz vers.
34c	Capacitor 30 uF	S000COE08	1	110V/60Hz/1ph. versions
35	Bottom plate	SSJ0PIC01 A	1	
36	Ground coffee outlet set	S00SGRC01	1	
37	Terminal blocks	P000MOA04	-	
38a	Contactore 230V/50Hz	S000COC02	1	Three phase 220-230V/50Hz vers.
38b	Contactore 380V/50Hz	S000COC08	1	Three phase 380-400V/50Hz vers.
39	Label: "Danger"	S000ETA14	1	110V/60Hz versions
40	Label: "Caution-Hopper"	S000ETA15	1	110V/60Hz versions
41	"Ground" plate	S000TAA18	1	
42	"External unipotential clamp" plate	S000TAA19	1	CE versions
43	Label: "Caution Fire"	S000ETA20	1	110V/60Hz versions
44	External unipotential clamp	-	1	CE versions
45	Ring O.R. 2056	S000ANA02	1	
46	Super Jolly cover bearing	SSJ0COA01	1	
47	Capacitor locking clamp 40	S000GRB05	1	
48	Under terminal board	P000SOT02	1	
49	Nut for cable locking 3213	S000DAA02	1	

